



*Weigh Pack Electrical*

# AIR WEIGH QUICKLOAD ONBOARD SCALES



**On-board scales take the guesswork out of loading, so you can get the most out of every trip.**

- Maximise every payload
- Save time on loading
- Eliminate overweight fines
- Stop paying scale fees
- Maximise service hours

**QuickLoad is the most economical scale with the same accuracy and durability as LoadMaxx. The scale does not include the advanced communication capability of LoadMaxx. QuickLoad is a good, low-cost choice for straight trucks, dedicated tractor/trailer, and tractor-only applications.**

## Specifications

- Measures steer, drive, GVW, and Net Payload
- Supports air ride and most mechanical suspensions
- Dual point calibration – empty and fully loaded
- Pin protected settings
- Alarm Outputs: Two, both with warning and overweight thresholds
- Temperature and Altitude Compensation
- Optional printer for instant weight receipts (RS-232)
- Accurate on-the-ground weights to within 1% (air ride) or 3% (mechanical) of a DOT certified scale
- Operating Temperatures: 0 deg to +50 deg C; 32 deg to + 122 deg F
- Inclinometer Option
- Units: Pounds or Kilograms; user selectable
- Power: 9 to 32 V dc
- Languages: English, Spanish, French and German
- Installation option: In-dash or mounting pod

## How Does My Scale Work?

QuickLoad works on trucks and tractors with air drive suspensions. Air sensors measure pressure in the air bags. The scale converts the sensor measurements into accurate on-the-ground weights.

## How Do I Use My Scale?

In order to get an accurate weight with your on-board scale, park your vehicle on level ground with the engine running and the brakes released. Briefly deflate the air suspension and inflate to ride height. Weights are displayed on the easy-to-read digital display.

## Tractor

- Standalone tractor application
- Accurately measures steer and drive axle group weights
- Available exterior alarm lights for overweight protection while outside the cab
- No communication between the tractor and trailer scale

## Dedicated Tractor/Trailer

- Designed for trailers that stay paired with the same tractor
- Measures steer, drive and trailer axle group weights, GVW and Net Payload
- Economical scale with same accuracy and durability as LoadMaxx
- Does not include advanced communication or app capabilities

## ALL AIR-WEIGH SCALES COME WITH THESE STANDARD FEATURES:

<b>Calibration</b>	Dual-point accurate, PIN protected
<b>Language</b>	English, Spanish, French & German
<b>Power</b>	Power – 9-32V dc
<b>Warranty</b>	Warranty – 3-year limited



**Email:** [Sales@weighpackelectrical.com.au](mailto:Sales@weighpackelectrical.com.au)  
[Service@weighpackelectrical.com.au](mailto:Service@weighpackelectrical.com.au)

**Phone:** 0488 199 318